

BAR INNOVATIONS

USER MANUAL

All plastic materials used in the manufacture of the Metrodispenser are approved by European regulations (Directive 2002/72/CEE) and the Food and Drug Administration (FDA) legislation of the United States of America (CFR 21, 177).

The Metrodispenser can be used with all types of beverages: Beer, wine, sodas, shots, spirits, mixers, juices, soft drinks, cider, cocktails... the list is endless.

MODELS

There are three Metrodispenser models, with varying capacities marked in litres - L, pints - Pt (UK) and ounces - Oz (US).

METRODISPENSER M

- Without cooling systems or with optional external Ice Sleeves, capacity: 2 L - 3.5 Pt (UK) - 67.6 Oz (US)

METRODISPENSER L

- Without internal cooling systems or with optional external Ice Sleeves, capacity: 3 L - 5.2 Pt (UK) - 101.4 Oz (US)

- If used with internal Ice Tube, capacity: 2 L - 3.5 Pt (UK) - 67.6 Oz (US)

METRODISPENSER XL

- Without internal cooling systems or with optional external Ice Sleeves, capacity 5 L - 8.7 Pt (UK) - 169.1 Oz (US)

- If used with internal Ice Tube, capacity: 3 L - 5.2 Pt (UK) - 101.4 Oz (US)

COOLING SYSTEMS

There are two cooling systems available as accessories.

- ICE SLEEVES (EXTERNAL)

Freeze the Ice Sleeves and slide them over the outside of the tube.

- ICE TUBE (INTERNAL)

Fill the Ice Tube with regular ice cubes. Then pour water into the Ice Tube until full. Then slide the Ice Tube into the dispenser and cover with the cap.

LEVEL MARKINGS

All three Metrodispenser models have double level markings, so that they may be used with or without the optional cooling systems.

The markings on the left show capacity (L, Pt, Oz) without a cooling system or with optional external Ice Sleeves.

The markings on the right show capacity (L, Pt, Oz) if the optional internal Ice Tube is used.

FILLING THE DISPENSER

Before filling the dispenser, chill the tube by rinsing briefly with cold water.

When filling with beer from a bar tap, tilt the tube and gently rest the inside surface against the end of the bar tap. This will allow the beer to slide down the tube without breaking into foam. If you wish you can add a touch of foam at the end for aesthetic purposes.

USING THE DISPENSER

Once full, place the tube into the portable base and serve drinks from the tap. The tap rotates around the base allowing all members of a group to serve themselves with ease.

With appropriate drinks, ice cubes may also be used inside the dispenser (independently of the optional cooling systems).

CLEANING THE DISPENSER

After use, rinse well and flush water through the tap. Clean the inside of the tube with warm water, conventional dishwashing liquid and our specially designed optional brush. The brush may be used for the main tube and also for the Ice Tube.

Wash tubes with warm water at a temperature no higher than 60 °C / 140 °F, and use mild detergents. Do not use cleaning products with contain amines, ammonia, solvents or high-gloss drying aids. The tubes may be washed in a dishwasher if the previous instructions are followed.

The Easy wash Hose, which includes universal water tap adaptors, is supplied as an optional rinsing accessory.

MAINTENANCE OF THE DISPENSER

The Metrodispenser may be fully disassembled for more thorough cleaning, thus guaranteeing total hygiene.

In the event of breakage or wear all parts may be purchased individually as spares.